

Handle Pattern: Full-size Boring for Bit Holder ξ., 11 Handle Boring for Screw ſ Ţ, _ i .i., Screwdriver Bit Chamber Ц., Boring for Magnet Cap Each square = 1/4" Hardwood Blank: 2" x 2" x 7"

Woodworker's Journal grants permission for readers to photocopy this Full-size Pattern, for personal use.