# **WORX**

### **WOODWORKER'S** JOURNAL

## **Build an Entry Bench**

Sponsored by WORX

Entry benches are a wonderful way to beautify and organize your home. This bench is made almost entirely from easy-to-find dimension lumber ... found at any home center. It's a project that almost anyone can build!

#### Dimension lumber and plywood required:

10 Pine: 1 x 2, 8 feet long


1 Pine: 1 x 3, 8 feet long1 Pine: 1 x 8, 8 feet long


6 Pine: 1 x 6 Tongue-and-Grove, 8 feet long

1 Birch Plywood: 3/4" x 48" x 48"

We recommend using a Kreg Jig and  $1\frac{1}{4}$ " pockethole screws to build the bench:

Rockler #22708 - \$39.00, Rockler #38502 - \$4.49





**Exploded View** 

#### Instructions

- 1. Cut all the dimension lumber to the lengths shown in the Material List, pieces 1 though 9, and pieces 14.
- 2. Glue the front and back legs into their "L" shaped configuration. Allow the glue to cure.
- 3. Drill pocket holes into the ends of pieces 4, 5, 6, 7, 9 and 14.
- 4. Start building the frame of the entry bench by attaching the Side Returns (pieces 3) between the front and back legs using pocket-hole screws.
- Complete the frame of the entry bench by attaching pieces 4, 5, 6, 7 and 9 between the side frames you just built. Piece 6 is located 15" up from the bottom of the back leas.
- 6. Attach pieces 14, mounting them 3/4" below the top edges of pieces 3 and 4.
- 7. Cut the Top Cap (piece 8), then mount it by gluing and clamping it to piece 7.
- 8. Cut out the Seat and Shelf (pieces 12 and 13).
- 9. Cut the Seat Side Frame and Front Frame to length (pieces 10 and 11).
- 10. Drill pocket holes into the bottom face of the seat, then attach the seat frame pieces with glue and pocket-hole screws. Set the seat assembly aside for now.
- 11. Fit the Shelf in place. Attach it with screws driven up through pieces 14.
- 12. Cut the Back Slats (pieces 15) to length. (Test the fit.)
- 13. Lay the entry bench on its front, then attach the Back Slats to the bench, starting at the top of the bench.
- 14. Rip the width of the bottom Back Slat to fit if necessary.
- 15. Stand the bench back on its legs, and put the Seat in place. You may attach the seat with screws driven up through pieces 5 or leave it loose. You choose.
- 16. Sand and finish the bench as you desire.
- 17. Attach hooks if you wish.

#### **MATERIAL LIST**

	TxWxL
1 Front Legs (4)	3/4" x 1½" x 16"
2 Back Legs (4)	3/4" x 1½" x 60"
3 Side Returns (4)	3/4" x 1½" x 13¾"
4 Front Top and Bottom Rails (2)	3/4" x 1½" x 45"
<b>5</b> Front and Back Seat Frames (2)	3/4" x 1½" x 42"
6 Middle Rear Stretcher (1)	3/4" x 5 <sup>1</sup> / <sub>2</sub> " X 39"
7 Upper Rear Stretcher (1)	3/4" x 3½" x 39"
<b>8</b> Top Cap (1)	3/4" x 3½" x 45½"
9 Lower Rear Stretcher (1)	3/4" x 1½" x 39"
<b>10</b> Side Seat Frame (2)	3/4" x 1½" x 17½"
11 Front Seat Frame (1)	3/4" x 1½" x 45"
<b>12</b> Seat (1)	3/4" x 16" x 43½"
<b>13</b> Shelf (1)	3/4" x 15½" x 42"
14 Shelf Supports (2)	3/4" x 1½" x 42"
<b>15</b> Back Slats (12)	3/4" x 5½" x 42"