




**Front Panel**  
(Side View)



**Side and Back Panels**  
(Side View)




**Exploded View**



**Note:** The width of the Front Panel reflects the use of a  $\frac{3}{32}''$  blade when removing the drawer front. If you use a blade with a different width, you must alter the piece to reflect the change.

**Foot Hole Locations**  
(Bottom View)



**Drawer  
Detail**  
(Top and Side Views)

